



#### **GENERAL SAFETY PRECAUTIONS**

DANGER: UNPLUG DEVICE WHEN NOT IN USE.

- DO NOT use near water.
- DO NOT immerse the device in water or use it in an area where it could be splashed.
- This appliance is not intended for use by young children or infirm persons unless they have been
  adequately supervised by a responsible person to ensure that they can use the appliance safely.
- Young children should be supervised to ensure that they do not play with the device.
- Use this device only for its intended function and do not use attachments not recommended by the manufacturer.
- Avoid wrapping the cord around the appliance. In time, this may cause the cord to break.
- CAUTION! The device becomes hot during use. Always avoid contact with skin.
- Never look directly into the airflow when device is in use.
- Do not use hair spray when the device is in use.
- Do not use an extension cord unless the cord complies with Australia/NZ electrical safety standards.
- Do not use the device if the cord is damaged. In the event of damage discontinue
  use immediately. If the supply cord is damaged, it must be replaced by the
  authorised manufacturer.
- Periodically inspect the power cord for signs of damage.



## **OPERATION**

## HOW TO OPERATE TEMPERATURE LEVELS/AIR FLOW

The device is supplied with 2 separate switches - a combination that will adjust speed and temperature. The 'Cold Shot' button can be pressed for an instant shot of cold air.

## HOW TO USE THE NOZZLE

Using the styling nozzle for directing air and creating desired results.

## SAFETY THERMOSTAT

Your dryer is fitted with a thermo cut-out. In case of over heating the dryer will stop functioning. After cooling down, the dryer can be used again.

## **CLEANING**

- Make sure the device is unplugged before cleaning.
- Clean the body of the device with care, using a damp cloth.
- The rear filter must be kept clean. In order to remove the filter for cleaning, turn it to the left and clean with care.



#### CAUTIONI

TO PREVENT DAMAGE TO THE DEVICE, DO NOT USE ALKALINE CLEANING AGENTS WHEN CLEANING. USE A SOFT CLOTH AND A MILD DETERGENT.



HANDY TIP

CLEAN THE REAR FILTER ON YOUR PROFESSIONAL HAIR DRYER DAILY.

### **USER INFORMATION. PLEASE KEEP.**

# Please retain this information for future reference.

## **Maintenance**

A periodic inspection should be made to ensure that your Cabello Professional Digital Hair Dryer is structurally intact and functioning properly.

All maintenance to be carried out by a suitably qualified tradesperson.

For more information about our products and services, please contact us visit us at **www.cabello.com.au**.



#### PROFESSIONAL USE ONLY

